DYNAPAC CA250D

SPARE PARTS CATALOGUE

SCA250D-3EN1

Box 504, SE-371 23 Karlskrona, Sweden
Phone: +46 455 30 60 00, Fax: +46 455 30 60 10
www.dynapac.com

Vibratory Roller
CA250D

Spare Parts Catalogue
SCA250D-3EN1

Valid from roller serial number:

**65821200* -*

Diesel engines:

CUMMINS QSB 4.5C

Published catalogue issues valid for these rollers:

Catalogue	*Issue date*	*Valid for serial numbers*
SCA250D-3EN1	*2007-05*	*See above*

RESERVDELSBESTÄLLNING

Följande uppgifter ska lämnas vid beställning av reservdelar för att undvika leveransfel:

1. Maskintyp.
2. Vältens serienummer.
3. Antal av önskad reservdel.
4. Reserdelens artikelnummer.
5. Reservdelens benämning.
6. Måttuppgifter vid beställning av metervara.

ORDERING SPARE PARTS

To avoid errors in delivery, please give the following information when ordering spare parts:

1. Type of machine.
2. Roller serial number.
3. Quantity required.
4. Part number.
5. Parts denomination.
6. Dimensions when ordering per length.

ERSATZTEILBESTELLUNG

Zur Vermeidung von Fehllieferungen sind bei der Bestellung von Ersatzteilen folgende Angaben zu machen:

1. Maschinentyp.
2. Herstellungsnummer.
3. Bestellmenge. (Quantity)
4. Ersatzteilnummer. (Part N°)
5. Ersatzteilbenennung. (Denomination)
6. Massangaben bei Bestellung von Meterware.

ORDINI DI RICAMBI

Per evitare errori nelle consegne di ricambi, Vi preghiamo di comunicarci le seguenti informazioni al momento dell 'ordinazione:

1. Tipo di macchina.
2. Numero di serie della macchina.
3. Quantità dei pezzi desiderati. (Quantity)
4. Numero di codice del pezzo. (Part N°)
5. Descrizione del pezzo di ricambio. (Denomination)
6. Misura, in caso di ordine per metro.

PEDIDO DE RECAMBIOS

Para evitar errores en las entregas, deberán indicarse los siguientes datos al hacer un pedido de recambios:

1. Tipo de máquina.
2. Número de serie.
3. Cantidad de piezas deseadas. (Quantity)
4. Número de artículo de la pieza de recambio. (Part N°)
5. Denominación de la pieza. (Denomination)
6. Indíquese la medida al solicitar un artículo que se expide por metros.

COMMANDE DE PIECES DE RECHANGE

Les indications suivantes doivent être fournies lors de la commande de piéces de rechange, afin d'éviter toute erreur de livraison:

1. Type de machine.
2. Numéro de série.
3. Quantité désirée de pièce de rechange. (Quantity)
4. Numéro de la piéce de rechange. (Part N°)
5. Dénomination de la piéce de rechange. (Denomination)
6. Longueur en cas de commande au mètre.

YOUR AGENT/DEALER:

Text pages

The text pages is structured as the picture on the right.

1. This is the remarks for specific items and the descriptions of the remarks is at the bottom of the parts list.
2. Parts indicated by a dot and moved to the right are included when buying the assembled unit above.
3. Spare parts and service code for a specific part, mainly for internal use at Dynapac. "A" = Service part, "B" = Fast moving part, "C" = Suggested exchanged part and "D" = Regular spare part.

DYNAPAC

Cooling system — Metso Dynapac AB

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	223047		1	Water cooler	C
2	935852		1	.Radiator cap	D
3	935851		1	.Cock	
4	373263	A	1	Radiator hose	D
5	313009		6	Clamp	
6	205058	B	1XL	Rubber clotch	
7	373261	C	1	Radiator hose	D
8			1	Oil cooler	D
9	223289		1	Plate	
10	902166	D	1XL	Edge trim	
11	223287	E	1	Holder	
12	223288	F	1	Holder	
13	908168		1	Fan guard	
14	908170		1	Fan shroud	
15	908171		2	Mounting bar	
16	908169		1	Fan guard	
17	500021		14	Screw	
18	902286		14	Nut	
19	600006		14	Washer	
20	313102		2	Cable strap	

A) Upper
B) L=060MM
C) Lower
D) L=2280MM
E) Left
F) Right

Changes

PARTS INFO	SERVICE INFO	GROUP	PAGE	NOTES

Notes

DYNAPAC

PÄRMETIKETT

För att undvika fel vid reservdelsbeställning finns här nedan två etiketter som passar i fickorna på pärmarnas ryggar. På dessa kan man se från vilket vältnummer av aktuell maskin reservdelskatalogen gäller. Gör så här:

1. Tag denna sida ur pärmen.
2. Klipp ut etiketten till **VÄNSTER** (1) och sätt in den i fickan på **DENNA** pärmens rygg.
3. Finns det en etikett till **HÖGER** (2), kan denna användas på pärmen för **FÖREGÅENDE** utgåva av denna katalog.
4. Kasta detta papper.

BINDER LABEL

To avoid errors when ordering spare parts use the labels below to identify the catalogues on the back of the binder. The label contain the serial number range for which the catalogue is valid. Do like this:

1. Remove this page from the binder.
2. Cut out the **LEFT** label (1) and put it on **THIS** binders back.
3. If there is a label to the **RIGHT** (2), it can be used on the binder for **PRECEDING** issue of this catalogue.
4. Throw away this paper.

KATALOG-BESCHRIFTUNG

Zur Vermeidung von Fehlen bei der Ersatzteilbestellung benutzen Sie bitte die unteren Beschriftungen, um die Kataloge auf der Rückseite zu kennzeichen. Auf der Beschriftung ist angegaben, für welche Maschinennummern der jeweilige Katalog gültig ist. Ablauf:

1. Nehmen Sie dieses Blatt aus dem Katalog.
2. Schneiden Sie die **LINKE** Beschriftung (1) aus. Schieben Sie die Beschriftung in die tasche auf **DEM** Katalogrücke.
3. Sollte die Beschriftung unten **RECHTS** (2) mitgeliefert werden, kennzeichen Sie damit bitte die **ÄLTERE** Ausführung dieses Kataloges.
4. Den Rest dieses Blattes bitte vernichten.

ETICHETTA POSTA SUL RACCOGLITORE

Per evitare errori quando ordinate pezzi di ricambio, usate le etichette in calce che servono ad identificare i cataloghi sul retro del raccoglitore. L'etichetta indica il numero di matricola delle maccine prese in considerazione nel catalogo.

1. Rimuovete questa pagina dal raccoglitore.
2. Ritagliate l'etichetta posta a **SINISTRA** (1) e ponetela sul retro **DEL** raccoglitore.
3. Se trovate anche un'etichetta sulla **DESTRA** (2), ritagliatela e ponetela sul raccoglitore relativo alla **PRECEDENTE** edizione del catalogo.
4. Distruggete questo foglio.

ETIQUETA PARA LA CARPETA

Para evitar errores al pedir repuestos utilicen las etiquetas abajo descritas para identificar los catálogos en la parte trasera de la carpeta. En la etiqueta se ven los números de referencia de la serie para la cual es válido el catálogo. Instrucciones:

1. Quitar esta página de la carpeta.
2. Corta la etiqueta **IZQUIERDA** (1) y ponerla est **ESTA** carpeta en la parte trasera.
3. Si hay una etiqueta en la parte **DERECHA** (2) se puede utilizar en la carpeta para el catálogo que **PRECEDE** a esta.
4. Tirar esta hoja.

ETIQUETAGE DU CATALOGUE

Afin d'éviter des erreurs lors de commandes de pièces de rechange, nous vous conseillons d'apposer les marquages ci-dessous à l'arrière du classeur, pour identifier les catalogues. Ce marquage indique les numéros de série pour lesquels le catalogue est adapté. Il convient de procéder de la façon suivante:

1. Retirez cette page du classeur.
2. Découpez l'étiquette de **GAUCHE** (1), et apposez-la à l'arrière de **CE** catalogue.
3. Si il y a une étiquette à **DROITE** (2), vous pourrez l'apposer sur le classeur de l'edition **PRECEDENTE** du catalogue.
4. Détruire cetta feuille.

1.

CA250D

Catalogue **SCA250D-3EN1**

Valid **from** serial number:

***65821200*-**

TABLE OF CONTENTS

Page

TABLE OF CONTENTS

Page

40
50
60
80
90
70
30
20
10
DYNAPAC
DYNAPAC

Ref. No.	Part No.	Rem.	Qty	Description		Code
10				Frames (Page 6)		
15				Side covers (Page 8)	Option	
30				Scraper and beam (Page 10)		
45				Scrapers, Urethan Rubber (Page 12)	Option	
55				Scrapers, Spring Steel (Page 14)	Option	
60				Hitch (Page 16)		
70				Structure (Page 18)		
80				Noise suppression (Page 20)	Option	

1
2
3
4
5
5
6
6
7
7
8
8
9
10
10
11
12
13
14
15

Ref. No.	Part No.	Rem.	Qty	Description		Code
1	392887		1	Tractor frame		
2	376701		1	Drum frame		
3			1	Hitch (Page 16)		
4	374744		1	Safety rod		
5	347119		2	Shaft		D
6	635061		3	Hair clip		D
7	904230		4	.Washer	10,5x22x2	
8	500043		2	Screw	M10x16H 8,8	
9	357488		1	Spring		
10	343775		2	Wire		
11	813391		1	Magnetic plug		D
12	372087		1	Protection plate		
13	904557		4	Washer	10,5x22x4	
14	500029		4	Screw	M10-1,5x30 8.8	
15	902919		6	Plug		

Side covers Option

16958

Ref. No.	Part No.	Rem.	Qty	Description		Code
1	380053		1	Side cover, right		
2	586003		2	Lock nut	M8	
3	387089		1	Holder, right		
4	387090		1	Holder, left		
5	380058		1	Side cover, left		
6	380057		1	Side cover, left		
7	380052		1	Side cover, right		
8	500053		16	Screw	M8-1,25x20 8.8	
9	381033		1	Cover		
10	904718		2	Wing screw		
11	904640		18	Washer	8,4x22x3	

Scraper and beam

17372

Ref. No.	Part No.	Rem.	Qty	Description		Code
1	376652		1	Cross beam		
2	384048		1	Scraper		
3	500102		4	Screw	M16x45	
4	904558		4	Washer	17x30x6	
5	904234		4	Washer	25x45x4	
6	500283		4	Screw	M24x120	

Scrapers, Urethan Rubber Option

18014

Ref. No.	Part No.	Rem.	Qty	Description		Code
1	376819	A	8	Scraper bracket		
2	376622	A	8	Holder		
3	904232		16	Washer	17x30x3	
4	500076		16	Screw	M16x55	
8	586019		18	Lock nut	M12	
20	376825	A	2	Scraper bracket		
21	358033	A	2	Scraper blade		B
22	904213		8	Washer	13x30x4	
23	376826	A	2	Scraper bracket		
24	904231		28	Washer	13x24x2	
25	500056		10	Screw	M12x45 8,8	
26	500049		8	Screw	M12-1,75x60 8.8	

A) Mounted on the front and rear of the drum.

Scrapers, Spring Steel Option

18012

Scrapers, Spring Steel Option

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	376819		8	Scraper bracket	
2	376829		4	Scraper	
3	376622		8	Holder	
4	904232		16	Washer	17x30x3
5	500076		16	Screw	M16x55
6	791948	A	8	Bolt	M12x40H 8,8
7	904703		8	Washer	13x24x4
8	586019		8	Lock nut	M12

A) Cup square neck bolt.

20
15
11
18
19
7
8,9,10
14
14
2
12
2
12
1
4, 5, 6, 21
3
16
12
2
17
12
2
14
14
7
19
18

Ref. No.	Part No.	Rem.	Qty	Description		Code
1	374900		1	Hitch		
2	100040		4	Axial ball bearing		D
3	373421		1	Bearing cover		
4	345871		N	Shim	T=1,0 mm	D
5	345872		N	Shim	T=0,35 mm	D
6	345873		N	Shim	T=0,10 mm	D
7	337042		2	Bearing cover		
8	337045		N	Shim	T=1,0 mm	D
9	345874		N	Shim	T=0,35 mm	D
10	345875		N	Shim	T=0,10 mm	D
11	343159		1	Cover		
12	167032		4	Lip-type oil seal		D
14	926214		4	Grease fitting		D
15	904229		1	Washer	8,4x16x1,5	
16	500287		12	Screw		
17	910995		3	Stop screw		
18	500037		12	Screw	M12-1,75x35 8,8	
19	904231		12	Washer	13x24x2	
20	500018		1	Screw	M8-1,25x12 8,8	
21	380993		N	Shim	T = 2,0 mm	D
	384498		N	Shim	T = 0,15 mm	D

9
17
27
22
40
39
41
26
21
25
16
1
47
46
45
48, 27
20
25
25
20
4
21
25
25
5
16
25
19
25
20
3
2
6
29
8
14
7
20
25
18
24
25
21
36
37
10
38
14
23
12
28
25
13
25
8
20
36
42
20
25
25
42
20
20
23
25
15
28
11

Ref. No.	Part No.	Rem.	Qty	Description		Code
1	392911		1	Hood		
2	389882		1	Protection cover		
3	392912		1	Hood		
	791475	A	2	Grommet		
4	382406		1	Rear cover		
5	376354		1	Cover		
6	392786		1	Holder, right		
7	376349		1	Holder, left		
8	376366		2	Holder		
9	380755		2	Holder		
10	380109		2	Holder		
11	450066		2	Door bumper		D
12	450067		2	Door bumper		D
13	381348		1	Holder		
14	381330		2	Holder		
15	381347		1	Holder		
16	381297		2	Cover		
17	380012		2	Holder		
18	500031		4	Screw	M10-1,5x40 8,8	
19	500047		4	Screw	M8-1,25x35 8,8	
20	500022		20	Screw	M8-1,25x30 8,8	
21	500053		10	Screw	M8-1,25x20 8.8	
22	924875		4	Screw	M6x35	
23	904504		8	Screw	M5 x 18	
24	904557		4	Washer	10,5x22x4	
25	904640		34	Washer	8,4x22x3	
26	382411		1	Hook		
27	902285		8	Lock nut	M6	
28	586001		8	Lock nut	M5	
29	902379	B	1XL	Edge trim		
30	902379	C	1XL	Edge trim		
36	381989		2	Holder		
37	904231		4	Washer	13x24x2	
38	500133		4	Screw	M12x70	
39	904228		2	Washer	6,4x12x1,5	
40	500040		1	Screw	M6-1x20 8,8	
41	586002		1	Lock nut	M6	
42	904281		8	Washer	5,3x10x1	
45	202028	J	1XL	Edge trim		
46	393857		1	Cover		
47	792549		1	Lock		
48	513012		4	Screw	M6x20 10,9	

A) With membrane
B) L=0,330 m
C) L=0,550 m
J) L=1,120 m

1
2
3
4
5

Noise suppression Option

Ref. No.	Part No.	Rem.	Qty	Description	Code
1		A	1	Hood	
2	393933	A	1	Noise suppression	
3	393932	A	1	Noise suppression	
4	390481	A	1	Noise suppression	
5	393934	A	1	Noise suppression	

A) Design does not always match picture

Ref. No.	Part No.	Rem.	Qty	Description		Code
10				Drum (Page 24)		
20				Drum cartridge (Page 26)	Drive side	
30				Drum cartridge (Page 28)	Vibration side	

Drum

16959

30
31
32
33
2
6
3
5
34
29
28
2
3
6
27
26
25
22
23
24
21
17
1
16
17
20
2
3
4
5
3
6
7
8
9
19
18
17
16
15
14
12
11
10
8
13

Ref. No.	Part No.	Rem.	Qty	Description		Code
1	372529		1	Drum		
2	500194		56	Screw	M12x40H 8.8	
3	904231		80	Washer	13x24x2	
4	500051		24	Screw	M12-1,75x25 8,8	
5	801187		10	Shock absorber		B
6	570007		56	Lock nut	M12	
7	373442	A	1	Gear holder		
8	904233		32	Washer	21x36x3	
9	903919		16	Screw		
10	500146		10	Screw	M24-3,0x110 8,8	
11	904234		10	Washer	25x45x4	
12	373443	B	1	Gear holder		
13	903281		16	Screw		
14	372236		1	Drive disc		
15	380462		1	Drum gear		
16	500082		23	Screw	M16x70	
17	904232		24	Washer	17x30x3	
18			1	Drum cartridge (Page 26)	Drive side	
19	349682		1	Drive shaft		
20			1	Drum cartridge (Page 28)	Vibration side	
21	384121		1	Air breather screw		B
22	527002		4	Drive screw		
23	343801		1	Sign plate		
24	232210		1	Plug		
25	925867		6	Nut	M20	
26	904233		6	Washer	21x36x3	
27	355677		1	Bracket		
28	904233		6	Washer	21x36x3	
29	928850		6	Screw	M20-2,5x120 10,9	
30	345678		N	Shim	T = 1,5 mm	
31	345679		N	Shim	T = 3 mm	
32	345884		N	Shim	T = 6 mm	
33	345885		N	Shim	T = 8 mm	
34	343322		1	Holder plate		

A) Right
B) Left

Drum cartridge Drive side

16963

Drum cartridge Drive side

Ref. No.	Part No.	Rem.	Qty	Description		Code
1	945584		1	Drum cartridge		
2	379876		1	.Bearing housing outer		
3	380018		1	.Splined shaft		
4	791156		8	.Screw M10-1,5x55 12,9		
5	390896		2	.Spherical roller bearing		D
6	343744		1	.Magnetic plug	M30	D
7	162017		2	.Seal ring	M30	D
8	900782		1	.Seal ring		D
9	381634		1	.Plug		
10	162027		3	.Sealing	M12	D
11	900775		6	.Plug		
12	900776		1	.O-ring		D
13	500163		3	.Screw	M12x16	
14	904232		12	.Washer	17x30x3	
15	500082		12	.Screw	M16x70	
16	381761		1	.Eccentric shaft		
17	232210		1	.Plug		
18	379880		1	.Bearing housing inner		
19	904737		1	.O-ring		
20	162011		1	.Washer, sealing		D

Drum cartridge Vibration side

18388

Drum cartridge Vibration side

Ref. No.	Part No.	Rem.	Qty	Description		Code
1	945588		1	Drum cartridge		
2	343744		1	.Magnetic plug	M30	D
3	162017		2	.Seal ring	M30	D
4	379880		1	.Bearing housing inner		
5	162027		3	.Sealing	M12	D
6	500163		3	.Screw	M12x16	
7	900782		1	.Seal ring		D
8	232210		1	.Plug		
9	381634		1	.Plug		
10	900775		6	.Plug		
11	379878		1	.Bearing housing outer		
12	904232		12	.Washer	17x30x3	
13	500082		12	.Screw	M16x70	
14	903189		3	.Stop screw		
15	900776		1	.O-ring		D
16	791156		16	.Screw M10-1,5x55 12,9		
17	380018		2	.Splined shaft		
18	390896		2	.Spherical roller bearing		D
19	381761		1	.Eccentric shaft		
20	162011		1	.Washer, sealing		D
21	904737		1	O-ring		
22	349715		1	Spring		
23	167023		1	Seal ring		D
24	381027		1	Splined sleeve		
25	116041		1	Taper roller bearing		D
26	390897		1	Shaft nut		
28	929447		1	V-ring		D
29	343318		1	Bearing housing		D
30	343322		1	Holder plate		
31	160105		1	O-ring 70		D
32	390771		1	Motor adapter		
33	162018		1	Sealing		D
34	370231		1	Plug		
35	904231		4	Washer	13x24x2	
36	500196		4	Screw	M12-1,75x80 8.8	
37	500082		8	Screw	M16x70	
38	384114		8	Spacer		
39				Not used on this model		

Ref. No.	Part No.	Rem.	Qty	Description		Code
10				Engine (Page 32)	Cummins QSB 4.5 C	
20				Cooling system (Page 34)		
30				Combustion air system (Page 36)		
40				Fuel system (Page 38)		
50				Exhaust system (Page 40)		

22
26
24
25
20
21
23
7
11
13
19
12
11
3
1
2
5
10
42
41
18
17
13
29
11
28
8
31
6
4
30
27
32
33
34
35
37
36
16
14
15
11
12
38
28
39
29
28
38
43
44
40
9
31
30
27
32

Ref. No.	Part No.	Rem.	Qty	Description		Code
1	391663		1	Diesel engine	Cummins QSB 4,5	
2	945731		1	.V-belt		B
3	945624		1	.Fuel filter element		A
4	945145		1	.Oil filter element		A
5	945140		1	.Alternator		C
6	945730		1	.Starter		C
7	392283		1	Engine bracket,	Right	
8	392284		1	Engine bracket,	Left	
9	393022		1	Engine bracket,	Left	
10	393021		1	Engine bracket,	Right	
11	904638		12	Washer	12x22x2	
12	508079		8	Screw	M12-1,75x35H 8,8	
13	500194		4	Screw	M12x40H 8.8	
14	370229		1	Coupling, cpl		
15	509025		8	Screw	3/8-16UNCx32 8,8	
16	372772		1	Bracket		
17	904637		12	Washer	10x18x2	
18	508029		12	Screw	M10-1,5x30H 8,8	
19	379163		1	V-belt cover		
20	393096		1	Connector		
21	382393		1	Fan hub		
22	379164		1	Fan		
23	792081		3	Socket head cap screw	M12x50 10,9	
24	904229		6	Washer	8,4x16x1,5	
25	500047		6	Screw	M8-1,25x35 8,8	
26	792275		4	Socket head cap screw	7/16-20UNFX32 12.9	
27	387129		4	Shock absorber		D
28	904232		5	Washer	17x30x3	
29	500070		4	Screw	M16x50	
30	904703		16	Washer	13x24x4	
31	500194		8	Screw	M12x40H 8.8	
32	586019		8	Lock nut	M12	
33	330333		1	Copper washer		D
34	379480		1	Reducer		
35	330331		2	Washer	18,2x23,9x1,5	
36	379621		1	Hydraulic hose		
37	904292		1	Hollow screw		
38	230515		1	Connector		
39	904233		2	Washer	21x36x3	
40	330383		1	Cap hydraulic		
41	791468		1	Hydraulic hose		
42	313035		1	Hose clamp		
43	388855		1	Bracket		
44	500154		1	Screw	M16-2,0x25 8,8	

69
68
61
25
18
27
30
46
6
62
21
63
26
46
53
29
20
7
44
11
10
9
44
55
1
69
65
68
68
22
35
39
70
63
40
21
44
40
21
2
34
31
22
39
8
36
38
67
21
71
37
22
21
44
32

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	392220		1	Radiator	
2	904551		2	Shock absorber	
6	392313		1	Expansion tank	
7	392297		1	Coolant hose	
8	393081		1	Coolant hose	
9	371774		2	Shock absorber	
10	904639		2	Washer	6,7x14x1,5
11	500012		2	Screw	M6x12
18	903714		1	Cap	
20	205027	A	1	Coolant hose	
21	904229		15	Washer	8,4x16x1,5
22	500053		14	Screw	M8-1,25x20 8.8
24	791597	G	1XL	Rubber strip	
25	921084		1	Pipe clamp	
	904228	J	1	Washer	6,4x12x1,5
	500040	J	1	Screw	M6-1x20 8,8
26	921063		1	Clamp	
27	313102		N	Cable ties	
28	902166	H	1	Edge trim	3-5
29	246069	B	1XL	Fuel hose	3/8"
30	246069	C	1XL	Fuel hose	3/8"
31	386853		1	Air inlet plate	
32	386943		1	Air leading plate	
34	904486		2	Quick lock	
35	387085		2	Fan guard	
36	902166	D	1XL	Edge trim	3-5
37	902166	E	1XL	Edge trim	3-5
38	902166	F	1XL	Edge trim	3-5
39	904640		8	Washer	8,4x22x3
40	500018		2	Screw	M8-1,25x12 8,8
44	313010		4	Hose clamp	
46	313075		4	Hose clamp	
53	381413		2	Washer	
55	902285		2	Lock nut	M6
61	392170		1	Holder	
62	500075		4	Screw	M6-1,0x25 8.8
63	313006		3	Hose clamp	
65	500048		1	Screw	M10-1,5x20 8.8
67	904352		1	Clamp	32x8,4x20
68	904230		6	Washer	10,5x22x2
69	500028		5	Screw	M10-1,5x25 8,8
70	393062		1	Holder	
71	500019		1	Screw	M8-1,25x16 8.8

A) L=0,7 m
B) L=1,28 m
C) L=1,65 m
D) L=0,33 m
E) L=0,69 m
F) L=0,45 m
G) L=0,62 m
H) L=0,47 m
J) Not illustrated

Combustion air system

184350

Ref. No.	Part No.	Rem.	Qty	Description		Code
1	348309		1	Rubber bushing		
2	393088		1	Air cleaner Cpl.		
3	908399		1	.Vacuator valve		D
4	908450		1	.Air filter element,	Main	A
5	908451		1	.Air filter element,	Safety	A
6	908452		1	.Cover		
7	813791		2	Mounting band		
8	393093		1	Air inlet hose		
9	392810		1	Hose clamp		
10	389600		2	Hose clamp		
11	393045		1	Charge air hose		
12	386966		6	Hose clamp	2.3/4"-3.5/8"	
13	385691		2	Air intake hose		
14	393058		1	Charge air tube		
15	904229		8	Washer	8,4x16x1,5	
16	500019		4	Screw	M8-1,25x16 8.8	
17	393059		1	Holder		
18	313093		2	Pipe clamp		
19	392742		2	Clamp		
20	904228		8	Washer	6,4x12x1,5	
21	500040		8	Screw	M6-1x20 8,8	
22	586003		4	Lock nut	M8	
23	904231		4	Washer	13x24x2	
24	500046		2	Screw	M12x30H 8,8 FZB	
25	392741		1	Holder		
26	393097		2	Clamp		
27	902285		2	Lock nut	M6	
28	499266		1	Protection cover		
29	904060		1	Hose clamp		
30	393085		1	Filter bracket		
31	904556		1	Washer	8,4x16x3,0	
32	500053		4	Screw	M8-1,25x20 8.8	

19
18
44
26
27
43
2
39
41
40
23
16
11
10
40
23
34
36
35
8
10
11
42
23
13
15
14
7
16
9
11
10
23
42
15
13
1

Ref. No.	Part No.	Rem.	Qty	Description		Code
1	373460		1	Fuel cap		D
2	904695		1	Fuel level sender		D
7	904984	A	1XL	Fuel hose		D
8	904984	B	1XL	Fuel hose		D
9	904984	C	1XL	Fuel hose		D
10	747282		4	Copper washer	14x20x1,5	
11	330171		2	Hollow screw		
13	373574		2	Hose connection		
14	244054	D	1XL	Hose reinforced		
15	313002		2	Hose clamp	13-20 mm	
16	313041		N	Cable ties	L=186 mm	
18	904281		5	Washer	5,3x10x1	
19	500006		5	Screw	M5x16	
23	313001		6	Hose clamp	11-17 mm	
26	904230		2	Washer	10,5x22x2	
27	500029		2	Screw	M10-1,5x30 8.8	
34	921084		1	Pipe clamp		
35	500040		1	Screw	M6-1x20 8,8	
36	904228		1	Washer	6,4x12x1,5	
39	230277		8	Copper washer	12,2x17,9x1,5	
40	792251		4	Banjo coupling	M12 Hose 8	
41	234919		4	Screw	M12-1,5-24-3	
42	901121		2	Banjo fitting	14x6 Hose 8	
43	945147		1	Pre-fuel filter element		A
44	945538		1	Fuel filter head with hand pump		

A) L=2,05 m
B) L=1,7 m
C) L=0,50 m
D) L=0,65 m

Exhaust system

18436

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	392294		1	Exhaust pipe	
2	392295		1	Muffler	
3	392296		1	Exhaust pipe	
4	386789		2	Clamp	
5	377098		1	Thermal guard	
6	392747		1	Thermal guard	
7	902166	A	1XL	Edge trim	3-5
8	902166	B	1XL	Edge trim	3-5
9	902166	C	1XL	Edge trim	3-5
10	313094		2	Pipe clamp	
11	904640		6	Washer	8,4x22x3
12	500053		4	Screw	M8-1,25x20 8.8
13	904229		4	Washer	8,4x16x1,5
14	313093		1	Pipe clamp	
15	500022		4	Screw	M8-1,25x30 8,8
16	393936		1	Thermal guard	
17	904231		2	Washer	13x24x2
18	500163		2	Screw	M12x16

A) L=0.080M
B) L=0,410M
C) L=0,380M

Ref. No.	Part No.	Rem.	Qty	Description		Code
17				Rear axle and wheels (Page 44)		
20	383857			Rear axle (Page 46)		
70	383856			Rear axle (Page 54)	No-Spin, Option	

Rear axle and wheels

18225-1

Ref. No.	Part No.	Rem.	Qty	Description		Code
1	383857		1	Rear axle (Page 46)		
2	929217		8	Screw		
3	904233		16	Washer	21x36x3	
4	901145		8	Lock nut	M20-10	
5	390590		2	Wheel, cpl		
	390762	A	2	Wheel, cpl		
	388145	A,G	1	Wheel, cpl		
	388146	G	1	Wheel, cpl		
6	383933		1	.Rim		
7	792261		1	.Air charging valve	Straight	B
8	390591		1	.Tyre		D
	791573	J,G	1	.Tyre		D
9	390588	B	1	Tractor wheel, cpl		
	390587	C	1	Tractor wheel, cpl		
	390759	D	1	Tractor wheel, cpl		
	390760	E	1	Tractor wheel, cpl		
10	383933		1	.Rim		
11	792261		1	.Air charging valve	Straight	B
12	390589		1	.Tyre		D
13	383974	F	2	Wheel, tubeless, cpl		
	383975	K	2	Wheel, tubeless, cpl		
14	383955		1	.Rim cpl		
15	901443		1	..Snap ring		
16	901444		1	..Side ring		
17	791175		1	.Air charging valve		
	791176		1	.Valve foot		
18	901218		1	.Tyre		D
19	355983	H	2	Decal "TYRE PRESSURE"	200kPa/29psi	
	903985	I	2	Decal "SAFETY", "TYRE IN BALLAST"		

A) Liquidfilled, option.
B) Left, option.
C) Right, option.
D) Liquidfilled tyre, right, option.
E) Liquidfilled tyre, left, option.
F) Option, Michelin branded.
G) For Chinese market only.
H) Used with item 13, 383974. 383975.
I) Used with Liqued filled tyres.
J) Used together with 388145 and 388146.
K) Liquidfilled, option, Michelin branded.

383857 Rear axle

17671

Ref. No.	Part No.	Rem.	Qty	Description	Code
1			1	Rear axle	
2			1	.Differential with limited slip (Page 48)	
3			2	.Differential housing and brakes (Page 50)	
4			2	.Planet gear (Page 52)	
5	909584		1	O-ring	D
6	909583		1	Flange	
7	929648		1	O-ring	D
8	901834		1	Splined sleeve	
9	909582		8	Screw	

Differential with limited slip

17672

Ref. No.	Part No.	Rem.	Qty	Description		Code
1	929638		1	Nut		
2	909574		1	Roller bearing		
3	939257		16	Bolt		
4	909572		16	Spring washer		
5	908485		1	Housing		
6	909568		1	Shim	0,10mm	
	909569		1	Shim	0,20mm	
	909570		1	Shim	0,50mm	
	939258		1	Shim	0,15mm	
7	909567		1	Spacer		
8	939259		1	Shim	0,15mm	
	909580		1	Shim	0,20mm	
	909576		1	Shim	0,30mm	
	929644		1	Shim	0,40mm	
	939260		1	Shim	0,50mm	
9	909581		1	Roller bearing		
10	212553		1	Bevel gear set		
11	929628		16	Washer		
12	929629		16	Screw		
13	923342		1	Bearing		
14	939261		2	Nut		
15	938989		2	Screw		
16	909550		1	Differential carrier		
17	909551		1	Shim	0,30mm	
	909552		1	Shim	0,40mm	
	909553		1	Shim	0,10mm	
21	909558		2	Differential gear		
22	909566		1	Shaft		
23	909559		4	Friction washer		
24	939262		4	Differential pinion		
25	909561		3	Rolled pin		
26	909560		2	Shaft		
27	909565		1	Shaft retainer		
28	909562		1	Differential carrier cover		
29	909563		8	Screw		
30	935644		2	Disc kit		D
31			10	.Limited slip disc		D
32			8	.Limited slip disc		D
33			2	.Limited slip disc		D

4
5
6
3
7
8
11
10
1
2
1
9
1
2
1
6
16
18
19
12
13
14
15
20
21
31
1 . 32
32
32
24
25
26
22
30
23
32
29
28
27

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	909609		6	O-ring	D
2	939255		2	Cover	
3	939256		1	Housing	
4	938984		1	Vent nipple	
5	909544		2	Screw	
6	938983		2	Seal washer	
7	909607		1	Seal	D
8	909596		1	Plug	
9	926810		1	Magnetic plug	
10	938296		1	Plug	
11	929617		1	Lock ring	
12	909616		2	Spring	
13	909618		4	O-ring	D
14	939280		2	Piston	
15	909619		4	O-ring	D
16	939281		4	Bolt	
17	938984		2	Vent nipple	
18	939282		2	Bolt	
19	939036		2	Seal washer	
20	939035		4	Screw	
21	939283		2	Disc	
22	939285		2	Ring	
23	909622		2	Pinion	
24	900966		2	O-ring	D
25	939286		2	Locking plate	
26	909624		2	Screw	
27	909626		4	Bolt	
28	900957		4	Nut	
29	926847		4	Seal washer	
30	939026		6	Screw	
31	939287		2	Cover	
32	939284		2	Brake disc kit	
			12	.Brake disc	
			12	.Brake disc	
	909609		2	.O-ring	D

Planet gear

17673

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	939263		2	Axle case	
2	939003		32	Spring washer	
3	939264		24	Bolt	
4	939265		2	Seal	
5	939266		4	Bearing	
6	926781		20	Wheel screw	
7	901987		20	Wheel nut	
8	939015		4	Screw	
9	330333		6	Copper washer	D
10	909596		4	Plug	
11	939016		20	Nut	
12	939275		2	Locking plate	
13	939017		20	Stud	
14	929612		2	O-ring	
15	939276		2	Wheel hub	
16	938985		2	Magnetic plug	
17	939277		2	Half shaft	
18	909586		2	Seal	D
19	939019		8	Nut	
20	939278		8	Stud	
21	939279		2	Planet gear carrier Cpl.	
22	939267		2	.Circlip	
23	939268		2	.Ring gear	
24	939269		2	.Ring gear support	
25	939270		2	.Washer	
26	939271		6	.Seal	
27	939272		6	.Planet gear	
28	939273		6	.Bearing	
29	939274		2	.Planet gear carrier	

383856 Rear axle No-Spin, Option

17671

383856 Rear axle No-Spin, Option

Ref. No.	Part No.	Rem.	Qty	Description		Code
1			1	Rear axle		
2			1	.Differential (Page 56)	with No-Spin	
3			2	.Differential housing and brakes (Page 50)		
4			2	.Planet gear (Page 58)		
5	909584		1	O-ring		D
6	909583		1	Flange		
7	929648		1	O-ring		D
8	901834		1	Splined sleeve		
9	909582		8	Screw		

Differential with No-Spin

17689

Ref. No.	Part No.	Rem.	Qty	Description		Code
1	929638		1	Nut		
2	909574		1	Roller bearing		
3	908485		1	Housing		
4	939259		1	Shim	0,15mm	
	909580		1	Shim	0,20mm	
	909576		1	Shim	0,30mm	
	929644		1	Shim	0,40mm	
	939260		1	Shim	0,50mm	
5	909567		1	Spacer		
6	909568		1	Shim	0,10mm	
	909569		1	Shim	0,20mm	
	909570		1	Shim	0,50mm	
	939258		1	Shim	0,15mm	
7	212553		1	Bevel gear set		
8	929628		16	Washer		
9	929629		16	Screw		
10	938989		2	Screw		
11	939261		2	Nut		
12	923342		1	Bearing		
13	929630		1	Differential case		
14	929631		1	Spacer		
15	929625		8	Screw		
16	929626		1	Non-spin unit		
17	909581		1	Roller bearing		
18	939257		16	Bolt		
19	909572		16	Spring washer		

20
2
3
9
10
2
9
19
16
1
17
18
6
7
4
5
26
27
28
21
15
14
5
22
23
24
25
29
13
12
11
9
10
8

Planet gear

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	939263		2	Axle case	
2	939003		32	Spring washer	
3	939264		24	Bolt	
4	939265		2	Seal	
5	939266		4	Bearing	
6	926781		20	Wheel screw	
7	901987		20	Wheel nut	
8	939015		4	Screw	
9	330333		6	Copper washer	D
10	909596		4	Plug	
11	939016		20	Nut	
12	939275		2	Locking plate	
13	939017		20	Stud	
14	929612		2	O-ring	
15	939276		2	Wheel hub	
16	938985		2	Magnetic plug	
17	939277		2	Half shaft	
18	909586		2	Seal	D
19	939019		8	Nut	
20	939278		8	Stud	
21	939351		2	Planet gear carrier Cpl.	
22	939267		2	.Circlip	
23	939268		2	.Ring gear	
24	939269		2	.Ring gear support	
25	939270		2	.Washer	
26	939271		8	.Seal	
27	939272		8	.Planet gear	
28	939273		8	.Bearing	
29	939349		2	.Planet gear carrier	

Ref. No.	Part No.	Rem.	Qty	Description	Code
10				Propulsion system, Front (Page 62)	
15				Propulsion system, Rear (Page 64)	
17	371509			Propulsion motor (Page 66)	C
20				Vibration system (Page 68)	
30				Steering system (Page 72)	
60				Brake system (Page 76)	

21
17
3
15
10
14
21
16
3
8
11
11
17
16
18
20
15
7
1
9
4
6
2
14
4
5
3
19
7
6
4
4
5
13
12

Ref. No.	Part No.	Rem.	Qty	Description		Code
1	371509		1	Propulsion motor (Page 66)		C
2	904058		1	O-ring		
3	904230		6	Washer	10,5x22x2	
4	923384		4	Flange half		
5	904005		2	O-ring		
6	904638		8	Washer	12x22x2	
7	502132		8	Screw	UNC 7/16" x 22	
8	334132		1	Elbow 45, O-ring		
9	334138		1	Adapter		
10	372235		1	Hose guard		
11	791230		2	Elbow 45		
12	500101		2	Screw	M20x50	
13	903290		2	Washer	21x36x6	
14	483996		1	Hydraulic hose		
15	483190		1	Hydraulic hose		
16	483995		1	Hydraulic hose		
17	373016		2	Hose clamp		
18	373270		2	Hose clamp		
19	500032		2	Screw	M10 x 55	
20	373423		2	Spacer		
21	500029		4	Screw	M10-1,5x30 8.8	

30
41
34
39
59
38
37
71
7
11
8
4
13
9
68
6
10
9
12
21
20
18
19
1
18
20
21
70
69
2
3
5
19
69
28
31
30
61
61
69
71
35
70
25
8
24
62
24
28
60, 63
17
9
70
70
14
16
15

Ref. No.	Part No.	Rem.	Qty	Description		Code
1	380830		1	Propulsion pump		C
2	500046		4	Screw	M12x30H 8,8 FZB	
3	904213		4	Washer	13x30x4	
4	500021		6	Screw	M8-1,25x25 8.8	
5	900229		2	Measuring nipple		D
6	359550		1	Hydraulic oil filter, cpl		
	359551		1	.Filter head		
	359552		1	.Cleaning filter element	Maximum 50 hours use	
	372229	A	1	Hydraulic oil filter element		A
7	500028		5	Screw	M10-1,5x25 8,8	
8	904230		15	Washer	10,5x22x2	
9	334468		3	Adapter		
10	234243		1	T-connector		
11	380490		1	Filter bracket		
12	813499		1	Elbow 90, O-ring		
13	904229		12	Washer	8,4x16x1,5	
14	375999		1	Hydraulic motor		
15	500263		4	Screw	M18x60	
16	904793		8	Washer	19x34x3	
17	334248		1	Elbow 45, O-ring		
18	923384		8	Flange half		
19	904005		4	O-ring		
20	904638		16	Washer	12x22x2	
21	502132		16	Screw	UNC 7/16" x 22	
24	345243		1	Connection block		
25	500109		2	Screw	M10-1,5x65 8,8	
26	234875		1	Tee-connector o-ring		
28	792339		2	Straight connector orfs		
30	234958		4	Connector		
31	483610		1	Hydraulic hose		
34	234909		1	Straight connector		
35	334138		1	Adapter		
37	923371		1	Adapter		
38	374059		1	Check valve		
39	904282		1	Adapter		
41	484042		1	Hydraulic hose		
44	313102		1	Cable ties		
45	372235		1	Hose guard		
59	162008		1	Seal washer		
60	380717		2	Flange coupling		
61	509034		8	Screw		
63	904171		2	O-ring		
68	482010		1	Hydraulic hose		D
69	483558		2	Hydraulic hose		
70	482391		2	Hydraulic hose		
71	482182		1	Hydraulic hose		D

A) Spare part for ordinary service

371509 Propulsion motor

16542

371509 Propulsion motor

Ref. No.	Part No.	Rem.	Qty	Description	Code
1			1	Hydraulic motor, Cpl	D
2	937274		1	.Housing	
3	937275	1	1	.O-ring	
4	902928		2	.Plug	
	901453	1	2	..O-ring	
5	908432		1	.Plug	
6	937277		1	.Cylinder block, cpl	
7	935619		1	..Spacer	
8	937278		1	..Spring	
9	935621		1	..Spring retainer	
10	935622		1	..Ring retainer	
11	903570		9	.Piston	D
12	903571		1	.Pressure plate	D
13	935623		1	.Retainer guide	
14	935624		1	.Shim	
15	935625		1	.Holder	
16	935626		1	.Valve plate	
17	937279		1	.Thrust plate	
18	813822		2	.Pin	
19	935629	1	1	.Gasket	D
20	358388		2	.Plug	
21	908432		1	.Plug	
22	909252		4	.Screw	
23	909253		2	.Screw	
24	935630		1	.Screw	
25	937280		1	.End cap, cpl	
26	903053		1	..Bushing	
27	909255		1	.Spool	
28	923087	1	2	.O-ring	D
29	358388		2	.Plug	
30	935853		1	.Plug	
31	926658	1	1	.O-ring	D
32	935631		1	.Shaft	
33	901465		1	.Bearing	
34	901467		1	.Ring	
35	937281		1	.Seal carrier	
36	935632	1	1	.Seal	D
37	937282		1	.O-ring	
38	908773		3	.Screw	
39			1	.Cover	
40	937283		1	Seal kit	

1) Includes in item 40, Seal kit

Vibration system

18323

Ref. No.	Part No.	Rem.	Qty	Description		Code
1	234382		1	Adapter		
2	901155		1	Connector		
3	334135		1	Tee-connector		
4	334122		1	Adapter		
5	330383		1	Cap hydraulic		
6	334121		1	Straight connector		
7	904767		2	Flange adapter		
8	929226		4	Flange half		
9	904773		2	O-ring		
10	500030		8	Screw	M10-1,5x35H 8,8	
11	904230		14	Washer	10,5x22x2	
12	904781		1	Adapter		
13	901157		3	Measuring nipple		D
14	334205		1	Straight connector		
16	900430		4	Flange half		
17	904774		2	O-ring		
18	502019		8	Screw		
19	904229		8	Washer	8,4x16x1,5	
24	483286		1	Hydraulic hose		
25	483910		1	Hydraulic hose		
26	483911		1	Hydraulic hose		
27	483031		1	Hydraulic hose		
28	483397		1	Hydraulic hose		
29	373017		2	Hose clamp		
30	500028		4	Screw	M10-1,5x25 8,8	
31	500194		4	Screw	M12x40H 8.8	
32	904231		4	Washer	13x24x2	
33	380145		1	Hydraulic motor, vibration (Page 70)		C
34	160132		1	O-ring	124, 50x3, 00	D
35	500032		2	Screw	M10 x 55	
36	373270		2	Hose clamp		
37	373424		2	Spacer		
38	383958		1	Vibration pump		C
39	903877		1	O-ring		
40	502078		2	Screw		
41	904232		2	Washer	17x30x3	
44		A	1	Hydraulic pump		
45		A	1	Connection block		
46		A	1	Tee-connector		
47		A	1	Straight connector		

A) See section "Hydraulic propulsion"

380145 Hydraulic motor, vibration

16978

380145 Hydraulic motor, vibration

Ref. No.	Part No.	Rem.	Qty	Description		Code
			1	Hydraulic motor, vibration		
1	340863		1	.Splined sleeve		D
2	380078		1	.Hydraulic motor, vibration		
3	901387		1	..Snap ring		
4	937261		1	..Cover		
5	937264	1	1	..Seal ring		
6	937265	1	1	..O-ring		
7	901390		1	..Shim	T=0,3 mm	
8	901389		2	..Shim	T=0,1 mm	
9	938042		1	..Retainer ring		
10	938041		1	..Back-up plate		
11	901386		1	..Bearing		
12	937260		1	..Bearing ring		
13	901385		1	..Bearing		
14	938040		1	..Shaft		
15	937262		1	..Washer		
16	903495		1	..Retainer plate		
17	903494		7	..Screw		
18	938030		1	..Pin		
19	938036		1	..Spring		
20	938035		1	..Spring collar		
21	938031		7	..Piston		
	938038		1	...Piston		
22	938039		2	...Sealing ring		
23	938002		1	..Cylinder		
24	901391		1	..Pressure plate		
25	938037		1	..Washer		
26	937995		1	..Screw		
27	937256		1	..Housing		
28	937258	1	1	..O-ring		
29	937257		1	..Plate		
30	902655		2	..Screw		
31	927350		4	..Screw		
32	937993		1	..Pin		
33	937259	1	1	..Screw		
34	937674		1	.Seal kit		

1) Included in seal kit, item 34

T
L
37
42
P
R
35
47
1
45
46
26
43
15
33
22
21
23
24
25
18
32
6
7
31
30
14
5
10
8
9
12
11
41
40
34
38
27
28
29
39
44
48

Ref. No.	Part No.	Rem.	Qty	Description		Code
1				Hydraulic oil tank		
5	392483		1	Hydraulic pump		
6	500046		2	Screw	M12x30H 8,8 FZB	
7	904231		4	Washer	13x24x2	
8	232097		2	Flange half		D
9	904637		4	Washer	10x18x2	
10	904005		1	O-ring		
11	508029		4	Screw	M10-1,5x30H 8,8	
12	379481		1	Connector		
13	903831		2	Nut	M12	
14	334558	B	1	Elbow 90G with O-ring		
	334197	A	1	Elbow 90		
15	234626		1	Adapter		
17	570006		4	Nut	M10	
18	929123		1	Elbow 90, O-ring		
19	903812		2	Hydraulic hose		
20	371669		2	Straight connector		
21	372513		1	Hose clamp		
22	372514		1	Hose clamp		
23	904229		3	Washer	8,4x16x1,5	
24	586003		2	Lock nut	M8	
25	500023		1	Screw	M8-1,25x40 8,8	
26	813444		4	Elbow 90, O-ring		
27	379630		4	Bearing		
28	500044		4	Screw	M6x8	
29	313102		N	Cable ties		
30	792237		1	Elbow 90, O-ring		
31	338304		1	Connector		
32	910161		1	Measuring nipple		D
33	483049		1	Hydraulic hose		
34	813500		1	Elbow 45, O-ring		
35	483160		1	Hydraulic hose		
37	483498		1	Hydraulic hose		
38	392002		2	Steering cylinder		
39	234218		2	Tee connector		
40	483109		2	Hydraulic hose		
41	334121		1	Straight connector		
42	483497		1	Hydraulic hose		
43	376000		1	Steering valve (Page 74)		
44	334197		1	Elbow 90		
45	502034		4	Screw	UNC 3/8 - 16	
46	600008		4	Washer		
47	483280		1	Hydraulic hose		
48	234662		1	Elbow 45		

A) In use together with 334558
B) In use together with 334197

26
2
1
27
29
25
24
2
5
32
7
11
3
8
4
9
14
2
13
15
12
21
17
22
18
33
20

376000 Steering valve

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	938062	A	1	Dust seal ring	
2			1	Housing, spool and sleeve	
3	938063		1	Ball	
4	938064		1	Threaded bushing	
5	908780	A	1	O-ring	
7	911620		1	Bearing	D
8	938065		1	Ring	
9	938066		1	Cross pin	
11	902861		1	Cardan shaft	
12	938067		1	Set of springs	
13	938068	A	3	O-ring	
14	902862		1	Valve plate	
15	903457		1	Gear wheel set	
17	938069		1	End cover	
18	938070	A	7	Washer	
20	938071		1	Screw with pin	
21	935468		6	Spring washer	
22	938072		1	Name plate	
24	938073		1	Pressure relief valve	
25	902864		1	Spring	
26	938074		2	Shock valve	
27	929013		2	Ball	
29	929014		2	Rolled pin	
32	938075		1	Check valve	
33	935429		1	Seal kit	

A) Included in seal kit, item 33

16621-1

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	334389		1	Connector	
2	482056		1	Hydraulic hose	
3	900552		2	Adapter	
4	234888		1	Tee-connector	
5	482399		1	Hydraulic hose	
6	234843		1	Adapter	
7	482474		1	Hydraulic hose	
8	334205		1	Straight connector	
9	334524		1	Connector	

Ref. No.	Part No.	Rem.	Qty	Description		Code
10				Electric system (Page 80)		
20				Control panel (Page 82)		
50				Working lights (Page 84)	Option	
70				Rotating beacon (Page 86)	Option	
80				Back-up alarm (Page 88)	Option	
90				Compaction meter (Page 90)	Option	

22
80
48
30
28
68
27
29
69
10
18
32
24
31
23
25
26
54
49
28
11
4
5
51
21
52
53
50
59
16
9
35
8
3
78
1
55
56
79
7
65
66
6
67
57
58
64
63
62
61
60

Ref. No.	Part No.	Rem.	Qty	Description		Code
1	392506		1	Cable harness engine		
3	904020		1	Battery cable		
4	387427		1	Cable harness		
	791477		1	.Fuse holder		
	791479		1	.Fuse, 125A, Orange		
5	392937		1	Cable harness		
6	903760		1	Connection cable, coarse		
7	335607		1	Connection cable, coarse		
8	791503		1	Battery cable		
9	904018		1	Connection cable, coarse		
10	386999		1	Holder		
11	500004		4	Screw	M5 0,8x12 8,8	
16	470020		1	Battery		
18	903640		1	Battery switch		D
21	904229		13	Washer	8,4x16x1,5	
22	500053		6	Screw	M8-1,25x20 8.8	
23	791183		2	Relay		D
24	904228		8	Washer	6,4x12x1,5	
25	500013		2	Screw	M6-1x16 8,8	
26	570004		3	Nut	M6	
27	904036		1	Fuse holder		
28	904281		10	Washer	5,3x10x1	
29	500060		4	Screw	M5-0,8x20 8.8	
30	586001		2	Lock nut	M5	
31	500075		3	Screw	M6-1,0x25 8.8	
32	586002		3	Lock nut	M6	
35	389662		2	Strap		
48	345870		1	Plug		
49	902284		2	Nut	M5	
50	378745		1	Control unit, ECU		
51	500025		2	Screw	M8-1,25x50 8,8	
52	904556		2	Washer	8,4x16x3,0	
53	586003		5	Lock nut	M8	
54	904448		1	Relay		D
55	903768		3	Threaded stud		
56	570005		3	Nut	M8	
57	813434		1	Reducer		
58	903631		1	Temperature sensor	Hydraulic oil	D
59	960727		2	Clamp		
60	921072		2	Clamp		
61	902468		1	Connector		
62	338304		1	Connector		
63	813462		1	Oil pressure sender		D
64	903632		1	Temperature sensor	Engine	
65	904231		2	Washer	13x24x2	
66	500051		2	Screw	M12-1,75x25 8,8	
67	500019		1	Screw	M8-1,25x16 8.8	
68	904038		1	Fuse	40A	D
69	904037		1	Fuse	30A	D
78	500012		1	Screw	M6x12	
79	923008		1	Clamp		
80	904230		2	Washer	10,5x22x2	

Control panel

18492-1

Ref. No.	Part No.	Rem.	Qty	Description		Code
1	392507	B	1	Cable harness control panel		
2	387683		1	Distribution control plate		
3	385599		1	Buzzer		
4	238158		1	Ignition switch		D
	940451		1	.Key		
5	791647		1	Emergency stop		
6	392996		1	Control panel		
8	792083		N	Plug		
9	792414		1	Switch, RPM		
10	792461		1	Switch, vibration		
11	791185		1	Fuse box		
12	903782		4	Screw	M5x12	
13	570004		3	Nut	M6	
14	500075		1	Screw	M6-1,0x25 8.8	
15	904229		1	Washer	8,4x16x1,5	
16	500053		1	Screw	M8-1,25x20 8.8	
17	999027		1	Horn		D
18	500075		1	Screw	M6-1,0x25 8.8	
19	586002		1	Lock nut	M6	
20	791517		1	Connection cable		
21	901767		2	Screw	ST3,5x9,5 Black	
22	791211		N	Contact bridge		
23	901228		N	Fuse	15A	
	901227		N	Fuse	10A	B
	901225		N	Fuse	5A	B
24	791582		1	Switch, parking brake		
26	792317		1	Switch		
27	792318		1	Switch		
28	792435		1	Pilot lamp		
	792432		1	Illuminated block red		
29	792319		1	Pilot lamp,	Yellow	
	792315		1	Illuminated block yellow		
30	791587	A	1	Switch, working light		
35	791585	A	1	Switch, rotating beacon		
42	791583	A	1	Switch, driving light		
43	791584	A	1	Switch, warning blinkers		
44	792413	A	1	Switch, drive direction		
50	791588		1	Panel plug		
	792463	A	1	Switch, Power distribution		
51	791578		1	Switch, horn		
52	792462	A	1	Switch, TC & TM		
	791657		1	Switch, Hi-Lo Speed		
53	903956	A	1	Relay		D
54	394061		1	Decal		

A) Option
B) Control panel

37
36
35
37
34
35
34
33
18
29
28
18
31
25
4, 11
9
10
3
12
15
4, 11
30
18
14
31
2,4
20
15
30
32
33
19
20
9
10
12
3
14
15
20
2,4
41

Ref. No.	Part No.	Rem.	Qty	Description		Code
2	902227		2	Work light		
3	374029		2	Lamp shield		
4	901369		4	Bulb	55w H3	B
9	500053		6	Screw	M8-1,25x20 8.8	
10	904640		6	Washer	8,4x22x3	
11	904314		2	Work lamp		
12	374030		2	Bracket		
14	500040		8	Screw	M6-1x20 8,8	
15	904228		11	Washer	6,4x12x1,5	
18	925802		7	Cable ties	L=142 mm	
19	921039		8	Pipe clamp		
20	500012		3	Screw	M6x12	
25	904038		1	Fuse	40A	D
28	904543		7	Cable tie holder		
29	903436		7	Blind rivet		
30	392771		1	Cable harness		
31	392856		1	Cable harness		
32	373184		1	Cable harness		
33	392772		1	Cable harness		
34	904314		4	Work lamp		
35	921039		2	Pipe clamp		
36	791341		9	Clamp		
37	541702		11	Screw	M6x12	
41	384163		2	Protection		

Rotating beacon Option

16981

Ref. No.	Part No.	Rem.	Qty	Description		Code
1	999011	1	1	Rotating beacon		D
2	358452		1	Lamp holder		
3	500021		2	Screw	M8-1,25x25 8.8	
4	586003		2	Lock nut	M8	
5	904229		4	Washer	8,4x16x1,5	
6	500013		1	Screw	M6-1x16 8,8	
7	904228		1	Washer	6,4x12x1,5	
8	392773		1	Cable harness		
9	921039		1	Pipe clamp		
10	541702		1	Screw	M6x12	
11	389577	2	1	Rotating beacon		D

1) Is replaced by item 11, P/N 389577
2) Replaces item 1, P/N 999011

Back-up alarm Option

17984

Ref. No.	Part No.	Rem.	Qty	Description		Code
1	380798	A	1	Cable harness		
2	901224	B	1	Fuse	3A	D
3	377071		1	Bracket		
4	904910		1	Back-up alarm		
5	500053		2	Screw	M8-1,25x20 8.8	
6	904229		2	Washer	8,4x16x1,5	
7	500040		2	Screw	M6-1x20 8,8	
8	904228		2	Washer	6,4x12x1,5	
9	902285		2	Lock nut	M6	

A) Is connected to the main wiring harness.
B) Located in the fusebox on the control panel.

Compaction meter Option

17358

Ref. No.	Part No.	Rem.	Qty	Description		Code
1	372836		1	Bracket		
2	372008		1	Processor comp.meter		
3	500053		4	Screw	M8-1,25x20 8.8	
4	904229		4	Washer	8,4x16x1,5	
5	372784		1	Cable harness		
6	313102		N	Cable ties		
7	381351		1	Cable harness		
8	930151		1	Switch		D
9	383452		1	Compaction meter		
10	373096		1	Instrument box		
11	393543		1	Bracket		
12	904206		3	Screw	M6X16	
13	541526		4	Screw		
14	500079		4	Screw	M6-1x50 8,8	
15	902496		1	Clamp		
16	348213		1	Sensor, cpl		
17	902285		7	Lock nut	M6	
18	373140		1	Bracket		
19	904231		2	Washer	13x24x2	
20	902288		2	Nut	M12	
21	313041		N	Cable ties	L=186 mm	
22	500194		2	Screw	M12x40H 8.8	
23	373016		1	Hose clamp		
24	349435		1	Rubber part		
25	901190	A	1	Conduit		
26	903192		2	Grommet		

A) L=230mm

Ref. No.	Part No.	Rem.	Qty	Description	Code
10				Drivers platform (Page 94)	
20				Control panel (Page 96)	
40				Forward and reverse control (Page 98)	
52				Steering column (Page 102)	
100				Canopy (Page 104) Option	
110				Rops and fops (Page 106)	
120				Cab mounting (Page 108)	
130				Cab (Page 110) Screens	
140				Cab (Page 114) Door, left side	
150				Cab (Page 116) Interior rear mirror	
160				Cab (Page 118) Exterior, rear mirror	
170				Wiper arm with blade, front (Page 120)	
180				Cab (Page 122) Work light	
190				Cab (Page 124) Electric	

Drivers platform

18486

Ref. No.	Part No.	Rem.	Qty	Description		Code
1	377556		1	Seat		
	377518	A	1	Drivers seat, cpl		
	348331		1	Seat cover		D
2	508006		4	Screw		
3	904229		4	Washer	8,4x16x1,5	
4	380123	F	1	Grab handle		
5	901145		4	Lock nut	M20-10	
6	904233		4	Washer	21x36x3	
7	904230		8	Washer	10,5x22x2	
8	500029		4	Screw	M10-1,5x30 8.8	
9	376252		1	Step		
10	500195		16	Screw	M12-1,75x50 8.8	
11	904231		16	Washer	13x24x2	
12	372757		2	Shock absorber		D
13	903290		4	Washer	21x36x6	
14	347512		4	Washer		
15	500210		4	Screw	M20-2,5x100 8.8	
16	374471		4	Spacer		
17	373400		2	Shock absorber		D
21	392394		1	Platform		
24	500053		4	Screw	M8-1,25x20 8.8	
25	904229		8	Washer	8,4x16x1,5	
26	380727		2	Cover		
27	372494	E	1	Rubber strip		
28	372785		1	List		
29	927974		13	Washer	5x19x1	
30	904433		13	Blind rivet		
31	382582		2	List		
32	586003		4	Lock nut	M8	
33	379636		1	Seat switch		
34	902203		2	Plug		
35	383705		1	Instruction book holder		
	357643	G	1	Wire		
37	791226		4	Screw		

A) Option
E) L=2,4 M
F) Welded with platform 380113
G) Not illustrated

Control panel

18487

Ref. No.	Part No.	Rem.	Qty	Description		Code
1	387720		1	Control panel holder		
2	391784		1	Control panel		
3	387227		1	Control panel cover		
4	387545		1	Latch		
5	357855		2	Bushing		
6	904281		4	Washer	5,3x10x1	
7	904653		3	Screw	M5x16 A2-70	
8	513017		2	Screw	M6x30H 10,9	
9	500007		1	Screw	M5-0,8x22H 8,8	
10	791476		1	Nut	M5 -8	
11	378335		1	Control panel column		
12	902166	A	1XL	Edge trim	3-5	
13	387226		1	Column cover		
14	500505		2	Screw	M8x20 8.8	
15	904230		4	Washer	10,5x22x2	
16	500029		4	Screw	M10-1,5x30 8.8	

A) L=0,190 m

Forward and reverse control

18489

Forward and reverse control

Ref. No.	Part No.	Rem.	Qty	Description		Code
1			1	Forward and reverse control handle (Page 100)		
2	392899		1	Control bracket		
3	392900		1	Control lever		
4	904556		3	Washer	8,4x16x3,0	
5	508092		2	Screw	M8-1,25x20H 8,8	
6	586003		2	Lock nut	M8	
7	904556		2	Washer	8,4x16x3,0	
8	500021		5	Screw	M8-1,25x25 8.8	
9	904229		8	Washer	8,4x16x1,5	
10	586003		1	Lock nut	M8	
11	377019		1	Ball joint		
12	416034		1	Ball joint		D
13	377024	A	1	Cable	Forward/Reverse	
14	377020		1	Clamp		
15	377021		1	Spacer		
16	926537		2	Screw	M5-0,8x16H 8,8	
17	586001		2	Lock nut	M5	

A) L=1900MM

Forward and reverse control handle

18071-2

Forward and reverse control handle

Ref. No.	Part No.	Rem.	Qty	Description		Code
1	945407		1	Lever, cpl		
2	940374		1	.Handle kit, cpl		
			1	..Handle		
			1	...Button		
			1	...Cable		
			1	..Lockfluid		
			1	..Service information		
3			1	..Washer		
4			2	..Washer		
5			1	..Connector, receptable		
6			1	..Lock wedge		
7			2	..Pin		
8			1	..Rod		
9			1	..Nut		
10	377018		1	..Protection plug		
11	378759		1	..Handle top		
12	391379		1	.Lever		
13	377009		1	.Bellows		
14	570004		2	.Nut	M6	
15	377015		2	.Set screw		
16	391381		1	Bushing		
17	391382		1	Potentiometer with cable		
18	377016		1	Spring loaded pin		
20	377010		1	Bracket		
21	903945		1	Connector, plug		
22	903946		1	Lock wedge		
23	508068		1	Screw		
24	904563		1	Lock nut	M6	
25	927233		1	Nut		
26	391383		1	Screw		
27	903947		3	Pin		
28		B	1	Cable		
29	377011		1	Spacer		
30	377012		1	Friction washer		
31	391380		1	Cam washer		
33	377014		1	Spring washer		
34	586019		1	Lock nut	M12	
36	391386		1	Spirol pin		

B) Included in potentiometer Pos 17

2
3
1
2
6
5
4
11
5
6
7
8
9
7
8
9
10

Steering column

Ref. No.	Part No.	Rem.	Qty	Description		Code
1	372964		1	Steering wheel, cpl		
2	935614		1	.Turning knob		D
3	935613		1	.Cover		
4	928830		1	Rubber washer		
5	500031		2	Screw	M10-1,5x40 8,8	
6	904230		2	Washer	10,5x22x2	
7	355869		2	Spacer sleeve		
8	500048		2	Screw	M10-1,5x20 8.8	
9	904230		2	Washer	10,5x22x2	
10	902123		1	Steering column		
11		A	1	Bracket		

A) Included in control panel

17483

16
9
12
12
11
12
11
11
2
5
10
10
6
18
18
8
10
10
4
3
10
13
11
14
7
17
1
14
15
13
14
12
1
17
14
15

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	904340		2	Pipe clamp	
2	373746		1	Canopy profile	
3	373747		2	Canopy profile	
4	373748		1	Canopy profile	
5	373749		4	Canopy rib	
6	373750		2	Canopy anchor	
7	380963		1	Canopy anchor	
8	380964		1	Canopy anchor	
9	373906		1	Roof	
10	500021		16	Screw M8-1,25x25 8.8	
11	904229		44	Washer 8,4x16x1,5	
12	586003		22	Lock nut M8	
13	500153		4	Screw	
14	904228		8	Washer 6,4x12x1,5	
15	586002		4	Lock nut M6	
16	373907		2	Lath	
17	924791		2	Cover plate	
18	500022		8	Screw M8-1,25x30 8,8	

6
5
7
8
22
23
9
4
10
11
3
2
1
21
12
20
14
13
15
20
15
16
20
19
17
18

Ref. No.	Part No.	Rem.	Qty	Description		Code
1	372347		1	Rops		
2	370803		1	.Sign, rops		
3	624016		4	.Blind rivet		
4	904619		12	Blind rivet		
5	904734		19	Washer	8,4x26x4	
6	500239		19	Screw	M8-1.25x50	
7	904180		4	Plug		
8	372409		1	Fops roof		
	370792		1	.Sign, fops		
	624016		4	.Blind rivet		
9	372678		1	Absorbent		
10	376489		1	Absorbent holder		
11	376488		1	Absorbent holder		
12	372489		2	Rubber seal		
13	904562		12	Screw		
14	904234		12	Washer	25x45x4	
15	381330		2	Holder		
16	381353		1	Holder plate		
17	904640		8	Washer	8,4x22x3	
18	500022		8	Screw	M8-1,25x30 8,8	
19	381352		1	Holder plate		
20	377677		1	Seat belt	2"	
	379637	A	1	Seat belt	3"	
21	383225		2	Hook		
22	904734		4	Washer	8,4x26x4	
23	500100		4	Screw		

A) Option 3"

Cab mounting

18429

Cab mounting

Ref. No.	Part No.	Rem.	Qty	Description		Code
1	378308		1	Cab		
2	570005		4	Nut	M8	
3	377556		1	Seat		
	377518	D	1	Drivers seat, cpl		
4	927974		13	Washer	5x19x1	
5	904433		13	Blind rivet		
6	372785		1	List		
7	382582		2	List		
8	372494	A	N	Rubber strip		
9	791218		4	Screw	M20x200	
10	904233		4	Washer	21x36x3	
11	384759		4	Spacer		
12	500195		16	Screw	M12-1,75x50 8.8	
13	904231		16	Washer	13x24x2	
14	904229		4	Washer	8,4x16x1,5	
15	374606	B	2	Shock absorber	Green	D
16	372457		4	Back-up ring		
17	903290		4	Washer	21x36x6	
18	901145		4	Lock nut	M20-10	
19	904230		6	Washer	10,5x22x2	
20	500029		6	Screw	M10-1,5x30 8.8	
21	376252		1	Step		
22	374607	C	2	Shock absorber	Yellow	D
23	382397		2	Spacer		

A) L=2400 mm
B) Rear
C) Front
D) Option

40
39
42
41
44
43
29
45
46
30
29
28
36
37
27
30
49
45
32
35
52
33
37
31
119
51
120
25
59
50
47
46
45
34
55, 56
26
54
53
24
22
124
21
121
119
23
20
38
102
18
17
19
16
12
8
13
14
10
6
15
5
7
4
100
2
101
1
11
9
3

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	937380		1	Screen	
2	908545		XL	Seal list	
3	935278		1	List	
4	935279		1	List	
5	937381		1	Screen, left	
6	908545		XL	Seal list	
7	935280		1	List	
8	935281		1	List	
9	937382		1	Screen	
10	908545	D	1	Seal list	
11	935282		1	List	
12	935283		1	List	
13	937383		1	Screen	
14	908545		XL	Seal list	
15	935284		1	List	
16	935285		1	List	
17	937384		1	Screen	
18	908545	C	1	Seal list	
19	935286		1	List	
20	935287		1	List	
21	937385		1	Screen	
22	908545	A	1	Seal list	
23	935288		1	List	
24	935289		1	List	
25	938290		1	Screen	
26	908499	E	1	Rubber list	
27	935271		8	Washer, Flexible rubber	
28	935272		8	Washer, Black	
29	935273		4	Hinge	
30	935274		4	Screw	
31	935275		1	Rubber washer	
32	935276		1	Bracket	
33	935277		1	Lock pin	
34	935290		1	Window lock, right	
35	938291		1	Screen	
36	908545	B	1	Seal list	
37	935291		1	List	
38	379608		1	Cover	
39	938292		1	Screen	
40	908545	B	1	Seal list	
41	935293		1	List	
42	938659		1	List	
43	937389		1	Screen	
44	908499	F	1	Rubber list	
45	935271		12	Washer, Flexible rubber	
46	935272		12	Washer, Black	
47	935295		1	Screen holder	
49	935296		2	Washer	
50	935297		1	Bracket	
51	935298		2	Bracket	
52	935299		1	Bolt	
53	935300		1	Shaft	
54	935301		2	Lock	
55	935302		1	Rod	

A) L=1100 mm
B) L=1400 mm
C) L=1900 mm
D) L=2100 mm
E) L=2700 mm
F) L=3300 mm

40
39
42
41
44
43
29
45
46
30
29
28
27
36
37
30
35
32
31
25
34
26
24
22
21
23
33
119
120
59
49
45
52
51
50
47
46
45
53
54
55, 56
124
121
119
38
20
18
17
19
16
13
14
15
12
10
11
9
100
101
102
8
6
5
7
4
2
1
3

Ref. No.	Part No.	Rem.	Qty	Description		Code
56	935303		1	Ring		
59	379236		1	Cover		
100	908506		1	Holder		
101	908507		1	Emergency hammer		
102	908499	G	1	Rubber list		
119	904229		16	Washer	8,4x16x1,5	
120	500019		14	Screw	M8-1,25x16 8.8	
121	500053		2	Screw	M8-1,25x20 8.8	
124	903782		2	Screw	M5x12	

G) L=5 m

Cab Door, left side

16967-1

Ref. No.	Part No.	Rem.	Qty	Description	Code
	940678		1	Door, cpl	
1	390927		1	.Door frame	
2	935277		1	.Lock pin	
3	938017		1	.Lock	
4	908580		1	.Lock pin	
5	908581		1	.Washer	
6	908582		1	.Cover	
7	908583		1	.Bracket	
8	935248		1	.Turning mechanism	
9	935249		1	.Retainer	
10	935250		1	.Rod	
11	935247		1	.Leader	
12	935246		1	.Seal	
13	935244		1	.Door handle with key	
14	935245		1	.Seal	
15	935268		1	.List	
16	937391		1	.Screen	
17	908545	A	1	.Seal list	
18	935267		1	.List	
19	908545	A	1	.Seal list	
20	937392		1	.Screen	
21	935270		1	.List	
22	935272		8	.Washer, Black	
23	935271		8	.Washer, Flexible rubber	
24	935273		2	.Hinge	
25	935274		2	.Screw	
26	935269		1	.List	
27	935266		1	.List	
28	937390		1	.Screen	
29	935265		1	.List	
30	908545	B	1	.Seal list	
31	935276		1	.Bracket	
32	935275		1	.Rubber washer	
33	937393		1	.Screen	
34	908499	C	1	.Rubber list	
35	935253		1	.Lock	
36	938101		XL	.Brush profile	
38	938018		1	.Gas spring	

A) L=1400 mm
B) L=1100 mm
C) L=2700 mm

Cab Interior rear mirror

16008

Cab Interior rear mirror

Ref. No.	Part No.	Rem.	Qty	Description		Code
1	908623		1	Bracket		
2	535005		2	Screw	M5x12	
3	908624		1	Rear mirror		

Cab Exterior, rear mirror

16009

Ref. No.	Part No.	Rem.	Qty	Description		Code
1	371730	A	2	Rear view mirror, cpl		
	908265		1	.Rear view mirror		
2	908355		1	.Arm		
3	908625		2	.Sleeve		
4	904232		2	.Washer	17x30x3	
5	908626		1	.Spring		
6	586021		1	.Nut	M16	
7	908627		1	.Cap		
8	629066		1	.Spirol pin		
9	908628		1	.Cap		
10	908361		1	.Bracket		
11	904229		6	Washer	8,4x16x1,5	
12	500019		6	Screw	M8-1,25x16 8.8	

A) Option

Wiper arm with blade, front

16968

Wiper arm with blade, front

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	905306		1	Wiper blade	
2	905305		1	Wiper arm	
3	905304		1	Wiper motor	
4	937871		1	Cover	
5	908605		1	Symbol wiper	
6	908617		1	Switch	

Cab Work light

16007A

Cab Work light

Ref. No.	Part No.	Rem.	Qty	Description		Code
1	908267		4	Working light		D
2	908359		2	Distance		
3	904229		4	Washer	8,4x16x1,5	
4	500019		4	Screw	M8-1,25x16 8.8	
5	586003		2	Lock nut	M8	

17377

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	937870	A	1	Cable harness	
2	384403	B	1	Cable harness	
3	384402	C	1	Cable harness	

A) Main supply
B) Horn
C) Windshield wiper

Ref. No.	Part No.	Rem.	Qty	Description	Code
10				Decals (Page 128)	
20				Decals (Page 130)	

15
17
19
11
10
14
8, 9
18
DYNAPAC
1
20
7
4, 9
3
2
20
A
A
13,26
12
11
10
1
14
8, 9
18
DYNAPAC
20
3
4, 9
5, 9
7
20
2
27

Ref. No.	Part No.	Rem.	Qty	Description		Code
1	588176		2	Decal "LIFT POINT"		
2	904068		2	Decal "DYNAPAC"	L=1770 mm	
3	904723		2	Decal "MODEL CODE"		
4	377744		2	Reflector, yellow		B
5	358090		1	Product plate ce		
6	902915		4	Screw		
7	903459		2	Decal "SAFETY"		
8	904870		2	Lifting sign		
9	624005		12	Blind rivet	3,2x6,1	
10	903424		2	Decal "HOT SURFACE"		
11	903423		2	Decal "SAFETY"		
12	991990		2	Decal "TYRE PRESSURE"	110-150kPA/16-21psi	
	390900		1	Decal "TYRE PRESSURE"	110kPA/16psi	
13	903425		1	Decal "SAFETY MANUAL"		
14	903422		2	Decal "SAFETY"		
15	272373		1	Decal "HYDRAULIC OIL"		
17	384159		1	Instructions	Loading-Unloading	
18	908229		2	Safety decal		
19	358881		1	Pad lock		
20	382751		4	Decal "TIE DOWN POINT"		
25	791642		1	Decal "WARNING"	Use of starting fluid prohib.	
26	393691XX		1	Instruction Handbook		
27	960787XX		1	Product identif. decal "Dynapac"		

B
B
8
B - B
4
5
7
6
12
DYNAPAC
5
A
A
A - A
9
11
3
2
DYNAPAC
2
2
1

Ref. No.	Part No.	Rem.	Qty	Description		Code
1	904098		1	Decal "DYNAPAC"	L=1350 mm	
2	377742		4	Reflector, red		B
3	991658		1	Decal "FUEL"		
4	904068		1	Decal "DYNAPAC"	L=1770 mm	
5	377743		2	Reflector, white		B
6	373364		1	Slip protection		
7	373363		4	Slip protection		
8	272372		1	Decal "HYDRAULIC OIL"		
9	904835		1	Decal "BATTERY POWER"		
11	358881		1	Pad lock		
12	348331		1	Seat cover		D

Ref. No.	Part No.	Rem.	Qty	Description	Code
100				Standard equipment (Page 134)	

1
DYNAPAC
2
DYNAPAC
OPERATION
&
MAINTENANCE
3
Safety Manual
Sicherheitshandbuch
Säkerhetshandbok
DYNAPAC
DYNAPAC HEAVY EQUIPMENT AB
4
DYNAPAC

Ref. No.	Part No.	Rem.	Qty	Description	Code
1			1	Documentation	ISCA250D
			1	.Warranty registration card	
			1	.Operation and maintenance	ICA250
			1	.Spare parts catalogue	SCA250D
			1	.Instruction manual	Cummins QSB 4.5 C
2			1	.Operation / maintenance instruction	I5CA250
3			1	.Safety manual	RSAFE
4	358881		1	Pad lock	

Ref. No.	Part No.	Rem.	Qty	Description	Code
10				Tool equipment (Page 138)	
40				Pad shell (Page 140)	
100				Dy-Mic (Page 142)	
230				Heater (Page 144) Simple cab	

Tool equipment

17111-1

2
3
4
1
5
6 . 7 . 8 . 9
10 . 11 . 12 . 13
14
15
17
18
16
20
19

Ref. No.	Part No.	Rem.	Qty	Description		Code
1	355890		1	Tool set Cpl		
2			1	.Adjustable wrench		
3			1	.Screw driver		
4	902610		1	.Belt pliers		
5	311016		1	.Grease gun		
6			1	.Open end spanner	10mm	
7			1	.Open end spanner	13mm	
8			1	.Open end spanner	16mm	
9			1	.Open end spanner	18mm	
10			1	.Allen wrench	10mm	
11			1	.Allen wrench	12mm	
12			1	.Allen wrench	6mm	
13			1	.Allen wrench	8mm	
14			1	.Tool bag		
15			1	.Wheel nut key	30/32mm	
16	901220		1	.Pressure gauge		
17	372837		1	Tool box		
18	372658		1	.Lock		
19	500019		3	Screw	M8-1,25x16 8.8	
20	904640		3	Washer	8,4x22x3	

Pad shell

18170

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	382139		2	Pad shell	
3	500286		8	Screw	M20-2,5x140 8.8
4	586022		12	Lock nut	M20-8
5	904233		16	Washer	21x36x3
6	500206		4	Screw	M20-2,5X60 8.8
7	382572		4	Mounting screw	
8	570015		4	Nut	M20
9	382571		1	Hexagon sleeve	
10		A	1	Cross beam	
11	376551		18	Scraper tooth	
12	376622		18	Holder	
13	904232		36	Washer	17x30x3
14	500165		36	Screw	M16-2,0x75 8,8

A) See section "Frames".

3
21
9
1
5
22
5
4
7
9
1
3
10
16
4
5
11
12
7
3
10
11
13
12
16
12
6
20
7
5
4
1
9

Ref. No.	Part No.	Rem.	Qty	Description		Code
1	386390		1	Communicator box		
	508002		4	Screw		
3	386391		1	Antenna	Cpl	
4	921039		4	Pipe clamp		
5	904415		4	Screw		
6	386512		1	Cable holder		
7	386533		1	Cable harness		
8	930154		3	Contact piece, NC		
9	386392		1	Cable harness		
10	386506		1	Antenna holder		
11	904228		4	Washer	6,4x12x1,5	
12	500040		4	Screw	M6-1x20 8,8	
13	586002		2	Lock nut	M6	
16	909122		1	Grommet		
17	313102		N	Cable ties		
18	313041		N	Cable ties	L=186 mm	
20	901224		1	Fuse	3A	D
21	386507		1	Antenna holder		
22	904281		2	Washer	5,3x10x1	

14
1
2, 3
4
16
11
5
12
13
7
9
10
10
8
6

Ref. No.	Part No.	Rem.	Qty	Description		Code
1	379394		1	Heater box (Page 146)		
2	500019		4	Screw	M8-1,25x16 8.8	
3	904229		5	Washer	8,4x16x1,5	
4	903741		2	Fuse	20A Yellow Medium	B
5	921056		1	Clamp		
6	813434		1	Reducer		
7	330330		1	Seal ring		
8	387638		2	Hose connection		
9	391303		1	Hose connection		
10	313004		4	Hose clamp	19-28	
11	921132		2	Clamp		
12	387466		1	Cable harness		
13	394210		1	Cable harness		
14	904039		1	Fuse	50A Red High	D
15	313102		N	Cable ties		
16	937737	A	2XL	Hose		

A) L=3600 mm

379394 Heater box

18432

379394 Heater box

Ref. No.	Part No.	Rem.	Qty	Description		Code
10	939693		1	.Heater control valve		
11	938622		1	.Switch		
16	938621		2	.Rotary control		
19	313003		2	.Hose clamp	15-24	D
24	385134		2	.Lock washer		
25	384881	A	1	.Hose		
27	938638		1	.Fan		
28	938639		1	.Heater coil		
29	938645		1	.Bowden cable		
31	384762		1	.Wire		
33	384761		1	.Air filter element		
34	287597		1	.Relay		D

A) L=200 mm

NUMERICAL INDEX

NUMERICAL INDEX

NUMERICAL INDEX

NUMERICAL INDEX

NUMERICAL INDEX

NUMERICAL INDEX